





# MULTIPURPOSE FAN

AI-MPF MODELS



**INSTALLATION AND WARRANTY INFORMATION**



# TABLE OF CONTENTS

Contact Information .....	Page 3
Key Features .....	Page 4
Kit Contents .....	Page 5
Rubber Feet Installation .....	Page 6 - 9
Top Mode .....	Page 10
Bottom Mode .....	Page 11
Upright Mode .....	Page 12
On/Off and Connecting More Fans .....	Page 13
Warranty .....	Page 14



**If you are not 100% satisfied with your purchase, you can return your order for a full refund. Please contact us!**

## **Email**

support@acinfinity.com

## **Phone**

909-595-5173

## **Web**

www.acinfinity.com


## **Fax**

909-468-3807

# KEY FEATURES

## ANTI-VIBRATION RUBBER

Specially designed rubber feet help keep the noise level down when the fan is vibrating against a hard surface.



## DUAL BALL BEARINGS

Long life bearings rated at 67,000 hours. Also allows the fan to be mounted in any direction.

## ON / OFF SWITCH

A power switch located on the cord permits you to easily turn the fan on and off without having to unplug it.




## ADDITIONAL USB PORT

Each cabinet fan contains an USB port. Up to four fans can be powered through a single USB or outlet source.

## POWER ADAPTER


The power adapter can be attached to the fans USB, allowing it to be powered by an electric outlet.




## USB CONNECTOR

Allows the fan unit to be powered by a standard USB port, a common power source in home electronics.

# KIT CONTENTS



FAN UNIT WITH POWER SWITCH



POWER ADAPTER




SCREWS (x8)



RUBBER FEET (x8)



FRONT GUARD



BACK GUARD

---

## RUBBER FEET INSTALLATION

YOU MAY NEED



PHILLIP'S HEAD SCREWDRIVER

# RUBBER FEET INSTALLATION

## STEP 1




Place the screw inside the hole located at the rubber foot's base. Push the screw's head until its thread shows up on the other end.

You may require the assistance of a pen or screw driver. Do not push too hard or the entire screw will slip through the rubber feet.



# RUBBER FEET INSTALLATION


## STEP 2



Position the front guard on top of the fan's frontal frame, aligning each of the four screw holes. To locate the front of the fan, find the side that contains plastic beams.

# RUBBER FEET INSTALLATION


## STEP 3



Insert the rubber feet through the guard and onto the fan's screwhole. Turn until you feel the screw tightening but do not overextend or the screw will slip through the rubber feet. Depending on your setup, you may not need a rubber feet on every hole, please see pages 10 to 12.


# RUBBER FEET INSTALLATION

## STEP 4




Repeat to secure the back guard onto the backside of the fan. Please make sure the elevated side of the guard is facing outwards or it will come into contact with the fan's impeller. To power the fan, plug it into a USB port or using the power adapter, plug it into an outlet.

# TOP MODE




The Multipurpose Fan can be placed above electronics that have vents on the top, such as a modem box or gaming station, to help draw out hot air. You would need to install four rubber feet on the fan's base.

# BOTTOM MODE




The Multipurpose Fan can also be placed below electronics to help accelerate the rising hot air. Up to four units can be daisy chained together to create a base for larger electronics, see page 13. Eight rubber feet are required for each fan.

# UPRIGHT MODE



The Multipurpose Fan can also stand upright to help circulate air in narrow places such as inside a computer desk or home theater cabinet. The fan helps push hot air out, allowing colder air to come in. You would need to install four rubber feet on the fan's bottom.

# CONNECTING MORE FANS



Each fan unit includes an USB port that can connect to an another fan. Up to four fans can be powered through one dedicated USB port or outlet source.

A power switch located on the cord permits turning on and off the fan without having to unplug it. Any unit daisy chained will also be turned on and off, following the first unit.



# WARRANTY

This warranty program is our commitment to you, the original purchaser, that each product sold by AC Infinity will be free from defects in manufacturing for a period of one (1) year from the date of delivery. If a product is found to have a defect in material or workmanship, we will take the appropriate actions defined in this warranty to resolve any issues.

The warranty program applies to any order, purchase, receipt, or use of any products from AC Infinity. The program covers products that have become defective, malfunctioned, or expressively if the product becomes unusable. The warranty program goes into effect on the date of delivery. The program will expire one year from the date of delivery. If your product becomes defective during that period, AC Infinity will replace your product with a new one or issue you a full refund.

The warranty program does not cover abuse or misuse. This includes physical damage, submersion of the product in water, incorrect installation such as wrong voltage input, and misuse for any reason other than intended purposes. AC Infinity is not responsible for consequential loss or incidental damages of any nature caused by the product. We will not warrant damage from normal wear such as scratches and dings.



**If you are not 100% satisfied with your purchase, you can return your order for a full refund. Please contact us!**



**Copyright © 2013 AC Infinity Inc. All rights reserved.**

No part of the materials including graphics or logos available in this booklet may be copied, photocopied, reproduced, translated or reduced to any electronic medium or machine readable form, in whole or in part, without specific permission from AC Infinity Inc.